



Giving driveways the edge

Graveledge aluminium edging stops gravel migration by creating a barrier between the surface and neighbouring garden zones. Graveledge can be supplied in two different types of profiles to work effectively with straight and curved landscapes.

Why Graveledge?

- ✓ **Sustainable material**
made from recycled and recyclable aluminium.
- ✓ **Resistant to rust**
durable edging solution that stays forever perfect.
- ✓ **No concrete required**
save time and money on installation.

Technical data

Edging Height

40mm

Edging Thickness (top bead)

6mm

Edging Length

2500mm

Edging Foot Width

45mm

Fixing Stake Length

250mm

Minimum Radius by Hand

1000mm

Minimum Radius in Factory

300mm

Available Finishes

Mill finish /
powder coat to order

Material Specification

6063A Aluminium

Recycled Content

Part recycled /
100% recyclable



Discuss your project on:
0800 197 8885

Installation guidelines

- 1 Lay a thin dry-mix bedding layer (e.g. sharp sand and cement) beneath the Graveledge foot to approximately 5-10mm. This thickness can be varied to adjust levels as required. This also ensures continuous support under the foot of the edging. The edging should not require a wet concrete haunch unless in non-standard application.
- 2 Place the Graveledge onto the bedding layer and fix using the Graveledge fixing pins through the pre-punched holes in the foot of the edging. Ensure the pins are firmly secured in the ground and down to the foot of the edging. The number of pins required will depend on the application and site conditions but as a guide, allow 1 pin every 500mm. Additional staking is recommended when laying curves or where the area is subject to heavy traffic.
- 3 Use the strip connectors (provided) to link the lengths of Graveledge together. Slide halfway into the channel on the inside of the edging and connect to the next length of edging.
- 4 Install the Gravelrings and surface covering as per the guidelines provided.

These instructions are provided as a guide only and do not offer any warranty (express or implied) since site conditions and requirements can vary.

Where you are overlaying an existing surface (e.g. tarmac or concrete) the fastest fixing method is to nail down using a concrete nail gun or alternatively, drill a pilot hole in the existing surface and hammer in our Graveledge fixing pin or screw down using a concrete screw and washer.



Discuss your project on:

0800 197 8885